

Packet Tracer – Configure Wireless Security

Objectives

Create a home network with a secure wireless router

Introduction

In this activity, you will configure a wireless router to:

- Modify the default password.
- Modify the default SSID and do not broadcast
- Use WPA2 Personal as security method.
- Rely on MAC filtering to increase security.
- Disable remote management.

Step 1: Load the .pkt file

- a. Load the 5.1.2.6 Packet Tracer Configure Wireless Security.pkt file.
- b. Press the **power** button on Laptop1 to turn it off.
- c. Drag the **Ethernet** port to the **Modules** list to remove it.
- d. Drag the WPC300N module to the empty slot on Laptop1 and press the power button to boot Laptop1.

Step 2: Modify the default password.

- a. Click on the wireless router and select the **GUI** for configuration.
- b. Click Administration > Management
- c. Modify the router password to a stronger one. Change the password to aC0mpAny3. Note that the new password has 8 characters with upper and lower case digits and some of the vowels have been changed to numbers. Select Save Settings at the bottom of that screen.

Step 3: Modify the default SSID name and disable the broadcast feature.

- a. Click Wireless and modify the SSID name to aCompany.
- b. Select SSID Broadcast and click Disabled. Click Save Settings at the bottom of that screen.

Check the topology. Has Laptop0 lost connectivity with the wireless router? If so, why?

Step 4: Configure WPA2 security on the wireless router.

- a. Return to the wireless router GUI tab. Click **Wireless > Wireless Security**. Change Security Mode to **WPA2 Personal**. **AES** is currently the strongest encryption protocol available. Leave it selected.
- b. Configure the passphrase as aCompWiFi. Scroll to the bottom of the window and click Save Settings.

Step 5: Configure Laptop0 as a wireless client.

- a. Configure Laptop0 to connect to the wireless network using the security settings you configured on the wireless router.
 - 1) Select Laptop0 > Desktop > PC Wireless.
 - 2) Select **Profiles > New** and add any name for the profile.
 - 3) Select Advanced Setup in the lower right hand corner.
 - 4) Select Wireless Network Name and enter the new SSID name: aCompany
 - 5) Accept the default network settings by selecting Next
 - 6) Modify the Security using the dropdown box to WPA2-Personal and select Next
 - 7) Enter the pre-shared key: aCompWiFi and select **Next.**
 - 8) Save the profile.
 - 9) Select Connect to Network.
 - 10) If the Laptop does not connect successfully, return to the profile and edit. Check your typing of the SSID name and the pre-shared key.
- b. Close the PC Wireless window and click Command Prompt.
- c. Type **ipconfig /all** and take note of the IP address and MAC addresses.

Step 6: Configure WRS1 to support MAC filtering.

- a. Return to the wireless router's configuration page.
- b. Navigate to Wireless > Wireless MAC Filter.
- c. Select Enabled and Permit PCs listed below to access wireless network.
- d. Type in the MAC address for Laptop0 in the MAC 01: field. Notice the MAC address must be in the XX:XX:XX:XX:XX format.
- e. Scroll to the bottom of the window and click Save Settings.
- f. Reconnect **Laptop0** to the **WRS1** network.

Step 7: Test the MAC filtering of WRS1

- a. Add a second laptop to the topology.
- b. Press the **power** button on the new laptop to turn it off and replace the Ethernet card with a wireless one.
- c. Configure the new laptop with the security settings required to connect to the wireless router.

Why are you unable to associate with the access point?

Step 8: Disable remote management on the wireless router.

- a. Check the current status of remote management on the wireless router. Select Administration > Remote Access. If it is disabled, enable it.
- b. Select the Hacker PC and select the Desktop > Web Browser. Enter the address 192.31.7.100 and tap Go. You should be presented with the request for a userID and a password. Enter the valid information and you should be able to access the wireless router GUI. Exit the Desktop.

- c. Return to the wireless router's configuration page.
- d. Navigate back to **Administration > Management** and scroll down to **Remote Management**. Select **Disabled** and click **Save Settings** at the bottom of that screen.
- e. Return to **the Hacker PC** and select the **Desktop > Web Browser**. Enter the address **192.31.7.100**. You should no longer be able to connect via the Web browser.